



Customer Maintenance Parts List

Model SR10006
SR10000 6dot recorder



Note:


- Parts marked with a ©symbol are Customer Maintenance Parts (CMP).
- The contents of this CMPL are subject to change without prior notice as a result of continuing improvements to the instrument's performance and functions.



Item	Part No.	Qty	Description
1	B8801FC	1	Door Assembly
2	B8800BM	1	Hinge Pin Assembly
⊙ 3	B9901AE	1	Name Plate
⊙ 4	B8800AJ	1	Chart Cassette Assembly
5	Y9306ZX	2	Bolt
6	-	1	Dot Frame Assembly (see page 4)
7	B8800AB	1	Name Plate
8	-	1	Case Assembly (see page 6)
9	B9900CR	4	Name Plate
10	-	1	Name Plate
11	-	-	Name Plate (Customer Option)

Note :


⊙ (CMP)



	Item	Part No.	Qty	Description
⊙	1	B8800EQ	1	Front Cover 1
⊙	2	B8800ER	1	Front Cover 2
⊙	3	B9962FD	1	Stock Cover

Note :
⊙ (CMP)

Dot Frame Assembly




Item	Part No.	Qty	Discription
1	B8801FJ	1	Display Assembly (not /D6) } (select)
	B8801FU	1	Display Assembly (/D6) }
2	B9962ER	1	Sensor Bracket
3	B8801BA	1	Dot Printer Assembly (see page 5)
4	B8800DV	1	VFD Latch
5	B8801GG	1	Dot Junction PCB
6	B8801SF	1	Dot Driver PCB
7	B8801BZ	1	Driver FPC
8	B8800SN	1	RS422 COM PCB (/C3) } (select)
	B8800SP	1	Ether COM PCB (/C7) }
9	B9988DL	2	Screw
10	B8800DW	1	Disp. FPC Cover
11	B8801GJ	1	Dot SRCPU Assembly
12	B9900FZ	1	Battery Holder
13	B9900BR	1	Battery Assembly
14	B8800DY	1	EMC Earth Bracket
15	B9988DL	2	Screw
16	-	-	Name Plate (Customer Option)
17	-	1	Name Plate

Note :

◎ (CMP)

Dot Printer Assembly

5




Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
1	B8801BB	1	Frame Assembly	16	B9963CP	1	M-Pipe
2	B8801BC	1	Frame Sub Assembly	17	B8800DX	1	Main Shaft
3	B8801BD	1	Dot Frame	18	B9901PG	1	Ribbon Holder Assembly
4	B8800KV	1	Switch Lever	29	B9901PJ	1	Motor Assembly
5	B9962EN	1	Spring	19	B9901HL	1	Gear
				20	B9901HM	1	Gear
6	B9962EE	1	Gear A	21	B9901HN	1	Gear
7	B9962EF	3	Gear B	22	B9963DA	2	Holder Bushing
8	B9962EG	1	Gear C	23	B9963CF	1	Motor Assembly
9	B9962EH	1	Gear Cover	24	Y9306LS	2	Screw
10	B9962EJ	2	Motor Assembly	25	B9963CJ	2	Pulley Assembly
11	B8801BW	1	Swing Gear A	26	B9901EK	1	Lever Assembly
12	B8801BX	1	Swing Gear B	27	B9901EN	1	Spring
13	B9963EL	1	Swing Gear Cover	28	B9988DL	1	Screw
14	B9963CL	1	Carriage Assembly				
	-	1	Printer Head Assembly				
	-	1	Sub Carriage Assembly				
	-	1	Belt				
	-	1	Block				
	-	1	Screw				
15	B9963DF	1	Sensor Clamper				

Note:

© (CMP)


Case and Back Panel Assembly



Item	Part No.	Qty	Discription
1	B8800BP	1	Case Assembly
2	B8800BQ	1	Case Assembly
3	B8800BV	1	Case Gasket
4	B8800BW	1	Gasket
5	B9900CF	2	Gasket
6	B9900CD	1	Pin
7	Y9203EB	1	Screw
8	B8800KQ	1	Power Assembly (not /P1) } (select)
	B8800KR	1	Power Assembly (/P1) }
9	Y9305LB	2	Screw
10	B8801CA	1	Back Panel Assembly (not /P1) } (select)
	B8801CC	1	Back Panel Assembly (/P1) }
11	B8801SB	1	DOT STD. MOTHER PCB
	B9988DL	4	Screw
12	-	1	Terminal Assembly (see Page 7)
13	Y9308LB	3	Screw
14	B8800SE	1	A/D Board PCB
15	B8801SD	1	DOT STD. Scanner PCB

Note:

⊙ (CMP)




Item	Part No.	Qty	Description
1	B8800JJ	1	Terminal Assembly (not /P1) } (select)
	B8800JK	1	Terminal Assembly (/P1) }
2	E9655FX	3	Screw
3	B9988DL	1	Screw
4	B8800AP	1	Cover Assembly (not /P1) } (select)
	B8800AX	1	Cover Assembly (/P1) }
5	B8801CV	1	Input Terminal Assembly
6	B9901JC	1	Cover Assembly
7	Y9306LS	2	Screw
8	B9900EH	1	Bracket
9	Y9314LB	1	Screw
10	B9988DL	1	Screw
11	B9900BS	1	Name Plate
12	Y9406LK	1	Screw
13	B8800MA	1	Option Terminal Assembly (*1) }
	B8800MB	1	Option Terminal Assembly (*2) }
	B8800MC	1	Option Terminal Assembly (*3) }
	B8800MD	1	Option Terminal Assembly (*4) }
	B8800MH	1	Option Terminal Assembly (*5) }
	B8800MJ	1	Option Terminal Assembly (*6) }
	B8800MK	1	Option Terminal Assembly (*7) }
	B8800ML	1	Option Terminal Assembly (*8) }
14	B8800KG	1	Option Cover Assembly
15	Y9318LB	2	Screw
16	B8800NA	1	Option Terminal Assembly (*9) }
	B8800NB	1	Option Terminal Assembly (*10) }
	B8800NC	1	Option Terminal Assembly (*11) }
	B8800ND	1	Option Terminal Assembly (*12) }
	B8800NH	1	Option Terminal Assembly (*13) }
	B8800NJ	1	Option Terminal Assembly (*14) }
	B8800NK	1	Option Terminal Assembly (*15) }
	B8800NL	1	Option Terminal Assembly (*16) }
17	B8800JZ	1	Bracket
18	Y9318LB	1	Screw
19	Y9308LB	1	Screw

Note

Model Code	Suffix Code (options)						
SR10006 □ □ □ □	/A1						*1
	/A1			/C3			
	/A2						*2
	/A2			/C3			
	/A3						*3
	/A3			/C3			
				/C3			*4
	/A1		/R1				*5
	/A1		/R1	/C3			
	/A2		/R1				*6
	/A2		/R1	/C3			
	/A3		/R1				*7
	/A3		/R1	/C3			
			/R1				*8
			/R1	/C3			
	/A1				/C7		*9
	/A2				/C7		*10
	/A3				/C7		*11
					/C7		*12
	/A1		/R1		/C7		*13
	/A2		/R1		/C7		*14
	/A3		/R1		/C7		*15
			/R1		/C7		*16


© (CMP)



Item	Part No.	Qty	Description
1	B9901AX	1	Ribbon Cassette
2	B9565AW	1	Chart *1
3	B9900BX	2	Bracket Assembly
4	B8801FZ	1	CD-ROM for Manuals
5	-	1	Manuals

SPARES

© (CMP)



Note *1 Part number: B9565AW
 Minimum order quantity 10 units
 (1 chart /unit)